



*Applicability: HARLEY DAVIDSON*

---

**Cod. KRBEA-038 – INSTALLATION AND USE**

---



1. Turn off the engine.



2. Locate the connectors of the lambda sensors.



3. Connect the Rapid Bike wiring in-line with the stock connectors.

**WARNING:** the position of the lambda's connectors is the following

**TOURING MODEL 2010-13 – behind the left fairing**

**SOFTAIL and DYNA MODEL 2012-13 – under the seat and between the engine and the voltage regulator.**

4. Connect the 6 pin connector and the 2 pin connector to the Rapid Bike Easy module.



### Paramétrage

#### GREEN LED / LED VERDE



The green led shows the state of the device:

**Led off** = not powered.

**Led on** = powered, o2 sensor cold.

**Led flashing** = powered, o2 sensor hot, the device is working.

5. Set the trimmers as follows:

**Trimmer 1** = SETTING

**Trimmer 2** = FUEL RATIO

MAKE	MODEL	TRIMMER 1	TRIMMER 2
Harley Davidson	All models	1	+1

6. Turn on the ignition, the green led must turn on.
7. Turn on the engine and wait some minutes until the green led starts to flash.
8. Fasten the cover with the screws.

## **Dimsport Srl**

*Zona Industriale Madonnina - Loc. San Iorio*

*15020 SERRALUNGA DI CREA (AL) - ITALY*

*T (+39) 0142.9552 F (+39) 0142.940094*

*www.dimsport.it*

## **RapidBike**

**ASSISTENZA TECNICA – TECHNICAL SUPPORT**

*Tel. (+39) 0142.9552*

*E-mail: support.rapidbike@dimsport.it*

**UFFICIO COMMERCIALE – COMMERCIAL DEPT.**

*Tel. (+39) 0142.9552*

*E-mail: info.rapidbike@dimsport.it*



a company of  
una azienda del gruppo



---

***www.rapidbike.it***

---